Practical no. 1 Identifying various Hardware components of a network.

Computer network components are the major pasts which are needed to install the software. Some important network components are NIC, switch, cable, hub, souter and modern.

Following are major components required to install a network:


NIC:

NIC stands for network interface card.

It is a hardware component used to connect a computer with another computer onto a network.

There are two types of NIC:

I wired NIC II- wireless NIC



Wired NIC:

The wised NIC is present inside the mothersland. Cables and connectors are used with wired NIC to transfer data.

Wireless NIC:

The wixeless NIC contains antenna to obtain connection over wixeless network.

HUB:

A HUB is a hardware device that divides metwork connection amoung multiple devices. The process used by HUB consumes more bandwidth and limits the amount of communication.

Switch:

A switch is a hardware device that connects multiple devices on a computer network. A switch contains more

advanced features than HUB. Router: A vouter is a hardware device which is used to connect LAN with internet connection. A soutes works in network layer. It forwards packet based on information. Modern: A modern is hardware device that allows computer to connect internet over existing telephone line. It stands for modulator/Demodulator. It converts digital data into analog signal over telephone lines. Cables and Connectors: Cable is transmission media used for transmitting a signal. There are three types of cables: i- Twisted paix cable ii- Fibre-optic cable iii- Coaxial cable

Practical no. 2. Studing Network Card


NICS-sometimes called network casds - are the mechanisms by which computers connect to a network. NIC's come in all shapes and sizes, and they come is prices to suit all budgets.

Network compatibility:

Perhaps this is a little obvious, but sometimes people order the wrong type of NIC for network. Given the prevalence of Ethernet metworks, you are likely to have to specify metwork compatibility only when buying NIC for another networking system.

Port compatibility:

for twisted - pair cabling. If we want some



other connectivity, you need to be sure to specify your card accordingly.

Hardware compatibility:

Before installing a network card into a system, you must verify compatibility between network card and operating system. If you are using good-quality network cards from recognized manufactures, such verification should be little more than a formality.

Types of network interfaces:

Network interfaces come as add-in expension cards or as PCMCIA card and network. A network interface typically has at least two LEDs that indicate certain conditions:


Link light:

This LED indicates wheather a network connections exists between card and network.

Activity light: This LED indicates network activity. under normal conditions, the light should flicker sporadically and often. Speed Sight: This LED indicates that interface is connected at a certain speed. This feature is mosmally found on Ethernet NICs that operates at iombps/100mbps. Installing network cards: At some point in your networking carees, it is likely that you will have to install a NIC into a system. For that reason, an understanding of procedures related to NIC are installed. Built-in network interfaces: A built-in network interfaces is a double - edged swood. The upsides are that it does not occupy an expansion slot and the hard campatibility.

Practical no. 3 Coaxial Cable

Coaxial cable is commenly used by cable operators, telephone companies, and internet providers around the world to convey data, video and voice communication to customers. The three most common cable sizes are RG-6, RG-11 and RG-59: · ROT stands for "xadio guide." The number of various vessions of RG cable refer to diameter. They are also called RF cables. · most non-industrial coax is now known as RG-6, but installers may use a thicker cable, like RG-11. · RG cables used in homes should be 75 ohm impedance. There are several types of



F-type Connectors for RG-6 cables: · Compression connector · Screw-on connectors · Crimp-style connector What are coaxical cable? It is a type of cable that has an inner conductor. Many cables have an insulating outer jacket. i- Centre conductor: copper-clad steel. ii- Centre conductor bond- clean stripping polymer is utilized to block moisture migration. iii - Dielectric: polyeth lene providing machanically stable, closed cell foam with high VP. iv- First outer conductor: shelld with an aluminium polymes aluminium tape securely boneded to dielectric core. v- Integral messenger: a galvanized, carbon steel wire support member attached to cable by a separable web.


Practical no. 4

Twisted Pair Cable

Twisted pairs is the ordinary copper wire which connects home and many business computers to telephone company. Twisted paix cable is good for transferring balanced differential signals. How to make network cable?

To create network cable, you will first need equipment listed below:

- · Cat, Cat, Cat, or Cat, cable
 - · RJ- 45 connectors · Crimping tool
 - · Wire stripper or knife



Once you have necessary equipment needed to create a network cable, you need to determine type of network cable you want to create. There are two major metwork cables: i- Striaght through cable (TS68A) Computer to HUB, switch, router or wallii- Crossover cable (TS68A& TS68B) a. Computer to computer with no switch or hub. b. Network device to network device. For example, souter to souter.

Practical no. 5 Using a cable tester.


What is cable tester?

A cable tester is

A cable tester is a hand held electronic device. It is used to verify electrical connections in a cable network. Signal strength, particularly in computer networks, is crucial for data transmission.

When to use a cable tester?

Once you are ready to check if a cable is set up properly to achieve strong connection between source and destination. That type is, typically after installation/set up is complete. It is good practice to test system once all components are connected in order to assure the job has been done properly.



If the test shows connectivity troubleshoots,

Possible issues:

- · Connection between server and the computer(s) is weak.
- · Outside intexference causing data loss or decreased signal strength
- · Faulty cable

How to use cable tester:

- 1- Select the cable to be tested and make sure it is not plugged to any electrical power.
- 2- Visually inspect the cable for demage.

 3- Plug it into appropriate port on cable
- tester, connect other end to remote.
- 4- Switch tester on to test your cable. The tester will show results.

Practical no. 6 Configuring MAC address on Windows/Linux os.


A device's MAC address is assigned by the manufacturar, but it's not too hard to changeor "spoof" - those addresses when you need to Here's how do it, and why you might want to-What MAC address are used 701? At a Rowest networking level, network interfaces attached to network use MAC addresses to communicate with each other. When a browser on your computer needs to grab an web page from a server on internet, for example, that request passes down through several layers of TCP/IP.

Change a MAC address in Windows: First, open the Device manager. On windows 8 and 10, press Windows + X, and click "Device Manager" on Power user menu. On windows 7, press window key, type "Device Manages" to search for it, then click "Device manager" In device manages, under "Network adapters" section, right click network interface you want to modify, then select "Properties". Now, on the "Advanced" tab and select "Network address entry in "property" list. Enable value option and type your desired MAC address · Click "OK" when you're done. In Modern Linux distributions like Ubuntu, you'd click the network icon on top panal, click "Edit


Connections", select the network connection you want to modify, and then click "Edit". on the Ethernet tab, you'd enter a new MAC address in "Cloned MAC address" field, then save your changes.

Practical no. 7

Configuring IP address
on Windows. Sometimes, it's better to assign a PC its own IP address sather than letting your souter assign one automatically. Right now, the IP addresses for your PCs are other devices are automatically by your router using protocol known as Dynamic Host Configuration Protocol (DHCP). Set a static IP address in window 7.8 and 10. To change computers IP address in windows, you'll need to open "Network connections" window. Hit windows + R, type "ncpa. epl" into Run box, and then hit Enter. In "Network Connection" window, rightclick the adapter for which you want



to set a static IP address, then select "properties" command. Now select "Internet Protocol Version 4 (TCP(IPv4)" and then click "Properties" button. Select the "use the following IP address" option, and then type in IP address, subnet mask and default gateway that corresponds with network setup. Next, type in your preferred and alternate DNS server addresses. Finally, select "Validate settings upon exit" option so that windows immediately checks your new IP address and corresponding information to ensure that it works. when you've ready , click "OR" button. And then close out of network adapter's properties window.



Practical no. 8 Designing a Local Area Network.
Part 1: Determining your network Needs:
1. Count the number of computers you need to handle.
2- Decide if you want to create a wixeless network.
3- Determine if you want all network, devices to have internet access. 4- Measure the distances for all
hardwired devices. 5- Consider your future need.

Part 2:	Setting UP Basic LAN:
2- Setup 3- Connect 4- Connect 5- Connect	your network hardware. your souter. your modern to router. your switch to your router. your computers to open
server if 7- Verify	one PC as a DHCP you've just using a switch. network connection on each file and printer sharing.
8- Setup	file and printer sharing.

Practical no. 9 Troubleshooting network connectivity. Always start troubleshooting using these simple network troubleshooting steps to help diagnose and refine issue. 1. Check the hardwave: When you've beginning the troubleshooting process, check all your hardware to make sure it is connected properly, turned on and working. 2. Use ipconfig: Open the command prompt and type "ipconfig" into terminal. 3. Use ping and tracert: If your souter is working fine, and you have an IP address

starting with 169, the problems most likely located between your souter and internet. At this point, its time to use ping tool. You can Ping Google DNS sexuess by opening command prompt and typing "ping 8.8.8.8", you can also add "-t" at the end (ping 8.8.8.8-t). 4- Perform a DNS check: Use the command "nslookup" to determine whether there's a problem with server you're trying to connect 5- Contact the ISP: If all the above turn up no problems, try contacting your internet service provider to see if they're having issues. 6- Check on vivus and malewave protection:

Next, make suse your visus and malware tools are running correctly, and they haven't flagged anything that could be affecting past of your network and stopping it from functioning. 7- Review database logs: Review all your database logs to make suse databases are functioning as expected. If your network is working but your database is full or malfunctioning, it could be causing problems that flow on and affect your network performance.

Practical no. 10 a Network Printer. A network printer is a printer that is connected to a computer network and can be accessed from many different computers. Installation: Connect your network to your printer. The process for this varies from pointed to pointed. · If your printer is wi-fi capable, you can generally connect it y to network using built-in menu display. · Make sure your wi-fi printer is close enough to souter to get

solid signal.

Connectivity:

· Click start menu and select control panal Windows 8 users can press # win and type "control panal." · Select "devices and Printers" or "View devices and printers". · Click Add a printer at top of Window. · Select "Add a network, wireless or Bluetooth printer. · Select your network printer from list and click next. · Install necessary drivers if prompted. windows should be able to find and install correct drivers for most p &inters. Printing:

Point to the network pointer.

· make sure that printer is turned on and that you are connected to the same internet. SENON STIE HON OF GUTTA COVER

ILLUSTEATION

DUTTE CONTR.

- 2 COME OUT PHILDING
- 3 SUST LECE NUT, GASCET, AND BILATO CLAME ON CARE.

LOCK HUT

4 FOLD SHILDING OVER BIAND CLAMF AND TRIM DICESS

INNER COVER.

- S CUT INNER COVER TO 1718 INCH AND CONDUCTOR TO \$333 INCH AS SHOWN.
- A. TH CONDUCTOR AND REMOVE EXCESS SOLDER.
- 7. SOLDER CONTACT TO CONDUCTOR
- BOOK SLICE CONTACT INTO CO-SUCCION BOOK SLICE CASKET FORWARD AND TIGHTEN LOCK NUT SICURELY.

CONSTICTOR BOOM



ORD G1654

Practical no. 11 Terminating the coaxical cable. Procedure: Ensure dielectoic is securely seated into the compression connector. The dielectric should not pass through the hole at the end of compression Connector. The center conductor should extend slightly past the end of Compression Connector.

Practical no. 12. Using Network Moniters.

The network monitoring systems are used by the technicians to ensure availability and overall performance of system and network services. They allow admins to moniter sight to use, routers, slow machanisms, firewalls, core switches, client machine, and server performance. amoung other network data.

What does a network moniter

Network monitering is the use of system that constantly moniters a computer metwork for slow and failing components and that notifies the network administrator (via email, SMS or

other	alaxm	is) in	co	ise of	ou-	tages	or
	catag		of	netwo	yk r	nonitor	ing:
2· 3·	Availabi Configur Pexformat Cloud	ring	monit	itoring	*ing		